

CLEANING PROTOCOL ATTRACTION® / GTI MAX / CREATION 70 CLIC SYSTEM

PREREQUISITES:

- Clean the auto scrubber every day and empty the tank after each use
- Use the correct detergent, to the recommended dilution (follow the manufacturer's guidelines)
- Gerflor recommends the following chemicals; these are alkaline detergents. Gerflor does not guarantee effective cleaning from products not on this list. If products not included on the list are used, a chemical equivalence certificate should be provided.

EQUIPMENT TYPE		CHEMICAL	METHOD
INITIAL OR DEEP MAINTENANCE			
SWEEPING	Brush	See table DOSAGE: See table	Frequency: As necessary <ul style="list-style-type: none"> • Sweep • Clean with the scrubber-dryer (ensure vacuum suction is switched off), and allow the product to work for about 2 minutes • Work in strips, overlapping the lines • Complete the cleaning along the display units with the scrubbing brush and red pad • Clean the residual solution with a squeegee in areas inaccessible to the scrubber-dryer • Clean with the scrubber-dryer and vacuum
SCRUBBING	Scrubber-dryer + Untreated Soft Nylon Brush or Red Disc - 3M or equivalent Linatex Blade squeegee		
FINISHING	Cleaning trolley + Applicator + Red pad + Squeegee		
ROUTINE MAINTENANCE			
BALAYAGE	Brush	See table DOSAGE: See table	Frequency: Daily <ul style="list-style-type: none"> • Sweep • Clean with the scrubber-dryer • Work in strips, overlapping the lines • Vacuum • Complete the cleaning along the display units using a flat applicator equipped with a microfibre cloth
LAVAGE	Scrubber-dryer + Untreated Soft Nylon Brush or Red Disc - 3M or equivalent Linatex Blade squeegee		
FINITIONS	Cleaning trolley + Applicator + Microfibre cloth		

Note: DO NOT USE TOO MUCH WATER ON THE FLOORING to avoid the risk of water seeping between the tiles